

Digital Imaging (Cameras)

The following microSD / microSDHC Cards can be used with the microSD Card Attachment MASD-1.

[Caution]

- Compatible camera models with MASD-1 (as of Apr, 2008)
 - μ 1030SW / Stylus 1030SW
 - μ 1020 / Stylus 1020
 - μ 1010 / Stylus 1010
 - μ 850SW / Stylus 850SW
 - μ 840 / Stylus 840
- The microSD / microSDHC Card can be used only with the cameras compatible with MASD-1. The MASD-1 is different from the xD-Picture Card in form. Forcing it into an incompatible camera or any other equipment, it may damage camera or card or cause malfunction with the equipment. The images on the memory card may be destroyed.

The Panorama feature does not function with microSD / microSDHC Card.
To use the Panorama feature, use an Olympus xD-Picture Card.

Compatible microSD Card list

dated: 18/Apr.,2008

[microSD Card by TOSHIBA]

"X": Compatible "-" : Incompatible

Model name	Capacity	still picture	movie
SD-C256	256MB	X	X
SD-C512	512MB	X	X
SD-C01G	1GB	X	X
SD-C02G	2GB	X	X
SD-C04G	4GB	X	X*1

[microSD Card by SanDisk]

"X": Compatible "-" : Incompatible

Model name	Capacity	still picture	movie
SDSDQ-512	512MB	X	X
SDSDQ-1024	1GB	X	X
SDSDQ-2048	2GB	X	X
SDSDQ-4096	4GB	X	X *1
SDSDQ-6144	6GB	X	X *1
SDSDQR-8192	8GB	X	X *1

*1 You must have your camera firmware [version 1.1](#) or later for movie photography using 4GB or larger micro SDHC card.
If the camera firmware is version 1.0, the data in the card may be damaged.